

2002–2013 VFR800 VTEC (RC46) Power Outlet Accessory Bracket Installation



A: Bracket W/O Accessories



B: Bracket W/Accessories (Not Included)

What's included?

1 x Accessory Bracket



What tools are needed for installation?

1 x #2 Phillips Screw Driver



How to install?

1. Locate and remove the two (2) Philips headed screws securing the key bezel in place



2. Remove the key bezel



3. Place bracket onto the triple clamp and align the mounting holes



4. Reinstall the key bezel and fasten the two (2) Philips screws in reverse order



Note: This bracket is designed to hold any standardized accessory outlet that has a 1.13" diameter threaded mounting shaft as seen below.

